TWO TIMER

Owner's Manual



Thank you for your purchase of the Two Timer!

The TWO TIMER was inspired by the long discontinued Boss DM-2. The DM-2 was known for its warm haunting reverb and tape-like echoes. The TWO TIMER offers two Independent delay times which are foot selectable via the TWO TIMER's TIME 1/TIME 2 mode switch making it possible to have one delay setup for a short slapback rhythm sound while another is set to a longer delay for solos. It's essentially two great analog delays in one compact pedal. The TWO TIMER circuit features a BBD (Bucket Brigade Delay) for the warmth and character only analog can deliver, 1% Metal Film resistors for pristine audio quality and a True Hardwire Bypass for a clean signal path.

Contents Check List:

Before you begin, please check the contents of this box to insure that the following items are included:

- Two Timer
- Two Timer Owner's Manual
- 9VDC Power Adapter (North America Only)
- 9V Battery


If any of these items are found to be damaged or missing, immediately contact the BBE dealer from whom the unit was purchased.

We recommend reading this manual to familiarize yourself with all of the features of the Two Timer before using. Should you have any questions, please contact BBE at 800-233-8346.

Installing Battery

Pull the latch to the left with thumbnail to release the hinged battery compartment cover. Carefully unplug battery without straining cables.

Unplugging the input to the Two Timer will turn the unit off and conserve battery life.




Getting Started

- 1. Input
- 2. Output
- 3. On/Off L.E.D. effect status
- 4. Time 1-Adjusts time delay for Time 1
- 5. Time 2-Adjusts time delay for Time 2
- 6. Repeat Control- Adjusts amount of Repeats or Feedback
- 7. Mix Control- Adjusts ratio of Dry/Effect
- 8. On/Off footswitch
- 9. Time 1/Time 2 Mode footswitch On/Off L.E.D. Effect Status
- 10. Power Supply Inlet



Applications


Example #1



We recommend that you place the Two Timer after any overdrive/distortion or pre-amp for the most natural sounding effect.

Applications

Example #2



We recommend placing the Two Timer before any overdrive/distortion, pre-amp or amplifier for that early Van Halen sound.

* When using a Sonic Stomp we recommend placing it last in the signal chain and as close to your amp as possible.

Service

There are no user serviceable parts inside. Should the Two Timer require service please contact our Service Department for a Return Authorization at:

> BBE Sound, Inc. 800-233-8346 Ext.116

For service outside of North America please contact your local distributor. For a listing of BBE Distributors log on to: http://www.bbesound.com/distributors/dist.asp

Technical Specifications

Input Impedance: 1 MEG Ohms

Output Impedance: 1K Ohm

Delay Range: 0ms-330ms

Bypass: True Hardwire

Power Requirements: 9VDC (- Tip)

Battery Life: 30 hours

Dimensions: 3.7"(W) x 4.7"(D) x 1.8"(H)

Shipping Weight: 1.8 lbs.

Please Note: Due to continuing product improvement, specifications and design are subject to change without notice.

Warranty

Warranty registration of the unit to BBE Sound, Inc. is not necessary. It is strongly recommended that you retain a copy of the bill of sale for future reference.

IT IS THE SOLE RESPONSIBILITY OF THE END USER TO PROVIDE THE BILL OF SALE OR OTHER MEANS OF PROOF OF PURCHASE TO VALIDATE THE WARRANTY IF WARRANTY SERVICE IS REQUESTED.

The BBE Two Timer is warranted against defects in material and workmanship for a period of five (5) years from date of purchase from BBE Sound Inc. or from an authorized dealer. During this period, we will repair units free of charge providing that they are shipped prepaid to:

BBE Sound, Inc., 5381 Production Drive, Huntington Beach, CA 92649.

We will pay return UPS shipping charges within the USA. All charges related to non-UPS shipping, including customs clearance, will be billed. The warranty will be honored for the longer of either 90 days from the date of any service or the remainder of the original 5 Year factory warranty. This warranty will be consider null and void by BBE Sound, Inc. if any of the following is found:

- 1. The equipment has been physically damaged.
- 2. The equipment shows signs of abuse.
- The equipment has been electrically damaged by improper connection or attempted repair by the customer or a third party.
- 4. The equipment has been modified without authorization
- The bill of sales indicates that the purchase date of the equipment is not within the warranty period.

All non-warranty repairs are warranted for a period of 90 days from the date of service.

BBE Sound, Inc. is NOT LIABLE FOR CONSE-QUENTIAL DAMAGES. Should the unit fail to operate for any reason, our sole obligation is to repair it as described above.

DO NOT RETURN ANY PRODUCT TO THE ABOVE ADDRESS WITHOUT INSTRUCTIONS AND AUTHORIZATION ISSUED BY THE ABOVE LOCATION.

Important Safeguards

For your protection, please read these safety instructions completely before operating the appliance, and keep this manual for future reference.

Carefully observe all warnings, precautions and instructions on the appliance and described in the operating instructions supplied with the appliance.

INSTALLATION



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,

DO NOT REMOVE COVER (OR BACK).

NO USER-SERVICEARLE PARTS INSIDE.

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

ATTENTION: RISQUE DE CHOC ELECTRIC- NE PAS OUVRIR.



The lightning flash with amowhead symbol, within an equilateral triangle, is intended to aller the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient imaginate to constitute a risk of electric shock to persons.

The exclamation point, within a equilateral triangle



is intended to alert the user to the presence of important operating and maintenance (service) instructions in the literature accompanying the appliance.

nk, mol

Water and Molsture - Do not install the appliance near water for example, near a bathub, washowl, kitches nisk, laundry tub, in a wet basement, or near a swimming pool. Heat - Do not install the appliance near sources of heat such as radiators, heat registers, stoves, or other appliances that produce heat.

Verification - Situate the product so its location or position does not interfere with its proper verifilation. For example, you should not place the product on a bed, sofar, up, or similar surface that might block the vent openings, or placed in a built-in installation, such as a bookcase or cabinet that might impede the flow of air through the ventilation openings.

Wall or Celling Mounting - If your appliance can be mounted to a wall or ceiling, mount it only as recommended.

Accessories - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or

sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

USE

Power Source - Connect the appliance to a power supply only of the type described in the operating instructions or as marked on the appliance.

Power-Cord Protection - Route the power cord so that it is not likely to be walked on or pinched by having objects placed on it, paying particular attention to the plugs, receptacles, and the point where the cord exits from the appliance.

Grounding or Polarization - Do not defeat the grounding or polarization feature of the AC power cord. If your AC receptacle will not accept the power cord plug, contact your electrician to install a proper AC receptacle.

When not in use - Unplug the power cord of the appliance from the outlet when left unused for a long period of time. To disconnect the cord, pull it out by grasping the plug. Never pull the plug out by the cord.

AC Receptacle - Check to make sure that the AC recepta-

cle holds the power cord plug firmly and securely. If the power cord plug is loose, contact your electrician to replace the defective and unsafe AC

Foreign Objects - Be careful that foreign objects and liquids do not enter the enclosure through openings.

Cleaning - unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

SERVICE

Unplug the appliance from the wall outlet and consult qualified service personnel when:

- the power cord or the plug has been damaged.
- · a solid object or liquid has fallen into the cabinet.
- the appliance has been exposed to rain or moisture.
- the appliance does not appear to operate normally or exhibits a marked change in performance.
- the appliance has been dropped, or the enclosure damaged.

Do not attempt to service the appliance beyond that described in the operating instructions. For all other servicing, refer to qualified service personnel only.



5381 Production Drive Huntington Beach, CA 92649 714-897-6766 Phone • 714-896-0736 Fax

bbesound.com

BBE is the registered trademark of BBE Sound, Inc.